chef's planet

Important Use and Care Instructions

Improper placement or use of this Ovenliner may cause permanent damage to your oven.
Please read these instructions carefully prior to using the Ovenliner.

CAUTION

- Failure to use the Ovenliner as directed could damage your oven
- DO NOT use directly on oven element or open flame.
- DO NOT use above 500° F (260° C)
- DO NOT use self-clean mode with Ovenliner in oven – remove it first
- Clean the Ovenliner regularly – do not allow cooking fats or oils to build up
- DO NOT cover or block any holes inside the oven – covering holes could create unsafe carbon monoxide levels

PROPER PLACEMENT FOR ELECTRIC OVENS

For electric ovens with a visible heating element on the floor of the oven: Place Ovenliner on the bottom of the oven, under the element. Please note that the Ovenliner should be at least an inch below all parts of the element.

For electric ovens with no visible heating element on the floor of the oven: Place Ovenliner on the bottom wire rack of the oven NOT the floor of the oven.* You may place baking dishes and pans directly on the Ovenliner's surface.

PROPER PLACEMENT FOR GAS OVENS

Place Ovenliner on the bottom wire rack NOT on the floor of the oven.*

DO NOT cover or block any holes inside the oven. You may place baking dishes and pans directly on the Ovenliners surface.

If you are unsure of where to place the Ovenliner, place on the bottom wire rack NOT on the floor of the oven.*

Please note: Ovenliners are safe to use in convection ovens but we do we recommend placing the Ovenliner on the bottom wire rack of the oven. Please ensure that you trim the Ovenliner so that there is between 1 and 2 inches between all sides of the Ovenliner and the walls of the oven. You may place baking dishes and pans directly on the Ovenliner's surface.

Care and Cleaning

It is important to clean the Ovenliner regularly. Do not allow cooking fats or oils to build up on the surface of the Ovenliner. Chef's Planet Ovenliners are dishwasher safe or can be washed in warm soapy water. Wipe dry with a soft cloth. To preserve the nonstick qualities, do not fold the Ovenliner of use abrasive cleaners or sharp implements (economy grades can be folded without damage). After use some discoloration may occur but will not affect performance.

For Bird Owners

The Avian community has expressed concern regarding nonstick coated materials and their impact on birds. Published scientific tests have not revealed any dangers, however as a socially responsible company we do not recommend our Ovenliners for those who keep pet birds in the house. Severe cooking fumes, smoke, odors and misuse of nonstick coated cooking products can potentially cause damage to the health of pet birds.

*To ensure optimum heat circulation, trim the Ovenlliner to fit within the wire rack. The Ovenliner should not extend over the edges of the wire rack.